

T9 – RETARDANT POLYURETHANE DILUENT

USE: This thinner is especially prepared for the dilution of the “NEUCEPARKET 100”.
It can also be used to the cleaning of the application material.

COMPOSITION:

- Aromatic solvents.
- Glycol ether esters.

SPECIFICATIONS:

- **Density**.....0,880 ± 0,05
- **Color**.....Colorless
- **Aspect**.....Liquid, transparent.
- **Flashpoint**.....17 to 25°C

HANDLING: This thinner presents a moderate smell.
In the case of splashing to more sensitive areas of the skin or to the eyes, it can cause irritation. Usually a good washing of the splashed area, with clean water, is enough.
A certain care is recommended in the handling of this product.

STORAGE AND PACKAGING: This is a hygroscopic product. Therefore, packages should be kept properly closed, in good environmental conditions of temperature and humidity, and spend the product on the chronological order of supply.
Use it, with preference, up to 2 years after its manufactured date, but it can also be used after this date, as long as a good homogenization of the product can be verified.
It is supplied in packages of 1lt and 5 liters.